

# Flame Photometry

## Theory of Flame Photometry

### Definition:

- Flame photometry, or flame atomic emission spectrometry (FAES), is used to determine alkali and alkaline earth metals by analyzing the light emitted when a sample is introduced into a flame.

### Principle:

- Excitation:** Metal atoms in the flame get vaporized and excited to higher energy levels.
- Emission:** On returning to the ground state, they emit light at specific wavelengths unique to the element.

### Theoretical Basis:

- Boltzmann's Distribution:** Relates the ratio of atoms in ground vs. excited states at a given temperature.

$$\frac{\Delta N}{N_2} = \frac{g_1}{g_2} e^{-\Delta E/kT}$$

- Bohr's Theory:** Describes energy transitions:

$$\Delta E = E_2 - E_1 = h\nu$$

### Process Overview

- Sample Preparation:** Dissolve the sample in water or a suitable solvent.
- Atomization:** In the flame, the solvent evaporates, and the sample is vaporized. Metallic ions are reduced to free atoms.
- Excitation:** Electrons are thermally excited to higher energy levels.
- Emission:** Excited electrons return to the ground state, emitting photons of light.
- Detection:** A monochromator isolates the specific wavelength, and a photodetector measures its intensity.
- Calibration:** Emission intensity is compared to a standard calibration curve.

### Relation Between Emission and Concentration:

- The intensity of the emitted radiation  $I$  is proportional to the concentration  $C$  of the element:

$$I \propto C$$

- However, this proportionality holds true only within a specific concentration range. At very high concentrations, the relationship may become non-linear due to **self-absorption** or **saturation**.

### Flame Colors and Emission Wavelengths of Common Elements

| Element        | Flame Color    | Emission Wavelength(s) (nm) |
|----------------|----------------|-----------------------------|
| Lithium (Li)   | Crimson / Red  | 670.8                       |
| Sodium (Na)    | Bright Yellow  | 589.0, 589.6                |
| Potassium (K)  | Lilac / Purple | 766.5, 769.9                |
| Calcium (Ca)   | Orange-Red     | 422.7                       |
| Strontium (Sr) | Crimson / Red  | —                           |
| Barium (Ba)    | Apple Green    | 553.6                       |
| Copper (Cu)    | Blue-Green     | —                           |

### Advantages:

- Simple and inexpensive technique
- Rapid analysis
- Suitable for biological and pharmaceutical samples (e.g., serum electrolytes)

### Limitations:

- Only suitable for **alkali and alkaline earth metals**
- Less sensitive than **AAS or ICP-AES**
- Susceptible to **chemical and spectral interferences**

## Nebulisation in Flame Photometry

### What is Nebulisation?

- Nebulisation is the process of converting a liquid sample into a fine mist (aerosol) so it can be efficiently introduced into the flame for analysis.
- **It is a critical step in flame photometry because:**
  - It determines how uniformly the sample enters the flame.
  - It significantly affects the accuracy, precision, and reproducibility of the measurement.

### Process:

1. The sample solution is aspirated into a nebulizer, often through a capillary tube.
2. A high-velocity stream of gas (usually air or an oxidant like oxygen or nitrous oxide) breaks the liquid into tiny droplets.
3. This aerosol is then carried into the mixing chamber, where larger droplets settle, and the finer mist is directed toward the flame.

### Importance of Nebulisation:

- Ensures **efficient atomization** of the sample.
- Produces a **fine droplet size**, leading to more complete combustion and excitation.
- Provides a **consistent flow** of sample to the flame, reducing signal fluctuations.

## Components of the Nebulizer System:

### 1. Nebulizer (Aerosol Generator):

- Uses compressed air or gas (usually air or nitrous oxide) to break the liquid sample into fine droplets.
- Works on the Venturi principle, where high-speed gas flow creates a low-pressure region that draws up the sample and breaks it into an aerosol.

### 2. Spray Chamber (Mixing Chamber):

- Receives the aerosol from the nebulizer.
- Removes large droplets through impaction or gravity.
- Only the **fine mist** is allowed to pass into the flame.
- Helps to **stabilize** the aerosol flow, ensuring uniform delivery.

## Types of Nebulizers:

- **Concentric Nebulizer:** Most commonly used. Has an inner capillary for the sample and an outer tube for gas flow.
- **Cross-flow Nebulizer:** Uses perpendicular gas and liquid flows.
- **Ultrasonic Nebulizer:** Uses high-frequency vibrations to produce a fine mist; provides higher sensitivity.

## Factors Affecting Nebulization Efficiency:

### 1. Viscosity and surface tension of the sample:

- High viscosity reduces nebulization efficiency.

### 2. Gas pressure and flow rate:

- **Too high:** may cause splashing or unstable aerosol.
- **Too low:** insufficient aerosol production.

### 3. Orifice size and cleanliness of the nebulizer:

- Blockages can lead to inconsistent delivery.

### 4. Temperature and humidity:

- Can affect droplet size and evaporation.

## **Flame and Flame Temperature in Flame Photometry**

## Role of the Flame:

- In flame photometry, the flame serves two main purposes:
  1. **Atomization:** It converts the sample into free atoms by evaporating the solvent and decomposing compounds into atomic species.
  2. **Excitation:** The heat from the flame excites the atoms to higher energy states, which then emit light as they return to their ground states.
- The efficiency of both atomization and excitation depends on the type of flame and its temperature.

## Common Types of Flames Used:

### A. Air-Acetylene Flame:

- Most commonly used in flame photometry.
- Temperature: approximately **2300–2800°C**
- Suitable for alkali and alkaline earth metals like Na, K, and Ca.
- Provides moderate energy and relatively stable operation.

### B. Nitrous Oxide-Acetylene Flame:

- Hotter flame: approximately **2900–3100°C**
- Used when higher temperatures are needed, e.g., for elements with high excitation energies.
- Offers better atomization for refractory elements (e.g., Al, Ti), though rarely used in basic flame photometry.

### C. Air-Propane or Air-Butane Flame:

- Lower temperature (~1900–2000°C)
- Suitable for field work or portable instruments.
- Less commonly used due to limited atomization capacity.

## Flame Zones:

Understanding the flame structure is critical for positioning the burner and optimizing analysis:

### 1. Primary Combustion Zone (PCZ):

- Near the base of the flame.
- Incomplete combustion.
- Not suitable for observation; contains unburned fuel and radicals.

### 2. Interconal Zone (Inner Core):

- Just above the PCZ.

- Contains maximum population of neutral atoms.
- **Ideal region for emission measurements** because of high atom concentration and minimal ionization.

### 3. Secondary Combustion Zone (SCZ):

- Upper part of the flame.
- Complete combustion occurs here.
- Atoms are more likely to be ionized, leading to signal loss.

## Flame Temperature Significance:

- Determines the extent of atomization and degree of excitation.
- Too low a temperature → **incomplete atomization** → poor sensitivity.
- Too high a temperature → **ionization of atoms** or **excitation to non-emitting states**, leading to inaccurate results.
- Flame temperature must be **consistent** and **optimized** for the target analyte.

## Factors Affecting Flame Temperature:

### 1. Fuel-to-oxidant ratio:

- Lean flames (more oxidant) → hotter but more oxidizing.
- Rich flames (more fuel) → cooler, reducing environment.

### 2. Burner design and height of observation:

- Affects residence time of sample in flame and efficiency of excitation.

### 3. Gas flow rates:

- Optimized flow provides a stable flame; turbulence or backflame must be avoided.

## Control of Flame Temperature:

- Adjusting the fuel-to-oxidant ratio affects flame temperature and characteristics.
- Lean flame (more oxidant) is hotter but can cause excessive ionization.
- Rich flame (more fuel) is cooler and may not atomize all analyte particles.

## **Interferences in Flame Photometry**

- Several types of interferences can affect the accuracy and precision of flame photometric measurements.

## Types of Interference:

### 1. Spectral Interference



FREE PREVIEW

[Click here to visit our website](#)

PHARMACY PREMIUM NOTES

Complete subject  
and semesters are  
available on  
**FirstHope app only.**



[Scan or click here](#)

Click here to get the app



Available on Google Play

JOIN THE FIRSTHOPE COMMUNITY

Join our Telegram channel

Click here to join Telegram



[Scan or click here](#)

@FirstHopeNotes

**Instagram**

@firsthope.official

[Click here to follow >](#)

**YouTube channel**

FirstHope-Pharmacy / Live streams

[Click here to watch >](#)

**WhatsApp channel**

Follow FirstHope on WhatsApp

[Click here to join >](#)

**FirstHope website**

firsthopenotes.com

[Click here to visit >](#)

**B.Pharm / D.Pharm / M.Pharm / Pharm.D**

Preview notes. Complete subjects and semesters in the FirstHope app.